

DAYLIGHT SAVINGS TIME CHANGE FOR CTX/CIX (28,100,200,670)

FROM ANY EXTENSION WITH DISPLAY (IDLE)

Press [hold * # * # 1 * 2 * 3 *]

Display says

PASSWORD= [enter 0000 hold]

Display says

PROG= enter [902 hold]

Display says

PROG=902 1-2

SELECT PARAM

Press LED 2 (in most cases the "Line 1" button)

Display says

PROG=902 1-2

TIME=[enter time in 24 hr format (HHMMSS) hold, hold]

Display says

PROG= [enter## hold]

Display goes back to normal idle status and time should be whatever they entered.